

# SUPPORT BAR

INSTALLATION GUIDE

- Not sent with all doors -

Used for large return panels and oversized stationary panels

1 Loosen the glass clip. Align the slot to the fixed panel. The slotted screw head should be on the inside of the shower.

2 Rest the support bar on the fixed panel inside the tub. Level it and trace an arc on the wall.

3 Isolate the wall bracket and drill a hole, using a 1/4" drill bit through the wall. Locate the position of this hole by way of the wall bracket. Insert a wall plug.

4 Secure the wall bracket to the wall with the screw, and attach the support arm to the wall bracket.

5 Secure the glass fastener and set screws to complete the installation process.

